

DYE SUB FABRIC BANNER CARE



Our Dye-Sub Fabric banner is the perfect choice of indoor backdrop material. Made of 100% machine-washable polyester, our fabric is durable, fade-resistant, and easy to use, clean, and store. All of our banners are wrinkle-resistant, easily-foldable, and machine-washable. Our fabrics stay fade-free over many washes. Over time, with proper care, your printed large fabric backdrop will preserve its vibrancy and durability.



In the event you need to clean your fabric display, follow the steps below for the best results.

HANDLING TIPS

- Wrinkles can be removed with a **cool iron** or fabric steamer with a plastic head.
- Fabric should **NOT** be stored when damp or wet. Store in a cool, dry area.
- For storing banners, please remove any plastic packaging that was provided in shipping, and keep fabric in a cool, dry place. It is best to store wrapped in a breathable, natural fabric, such as cotton muslin or canvas. This can then be placed in a protective, sealed container. It is helpful to include a packet of silica drying beads in humid environments.
- Banners are meant for indoor use only. If the banner is hung for prolonged periods in sunlight or full-spectrum light, fading may occur in time.

WASHING

- Your fabric banner can be machine washed! Remove any hardware attached to the fabric prior to cleaning, if possible. Use MILD soap and cool water. Air dry fabric, dry on frame if frame is available.
- If grommets are included, make sure the fabric in and around the grommet is completely dry before storing. Fabric must be COMPLETELY dry prior to storing.
- **DO NOT DRY CLEAN**

STAIN TREATMENT

- Treat stains from the backside of fabric.
- Remove as much of debris as possible with a soft bristle brush (do NOT rub too hard)
- Use a clean, lint-free white cloth. Lightly pat the stain from the outside moving in (to keep stain from spreading)
- If a cleaning solution is used, rinse the area well with water to ensure NO solution is left on fabric.
- Most stains can be treated with household fabric stain removers. It is ALWAYS important to test how the solution will react to the fabric. This can be tested by dabbing the solution to a small corner of the fabric. Most household cleaners will provide treatment instructions depending on the type of stain.